

DIGEM 96 x 24 MF5	DIGEM 96 x 48 MF5	DIGEM 96 x 48 B5	DIGEM 96 x 48 AK5	DIGEM 96 x 48 MB5	DIGEM 96 x 48 SN5	DIGEM 96 x 48 CX5	DIGEM 144 x 72 C5	DIGEM 62 x 38 A5	DIGEM 62 x 38 B5	DIGEM 72 LCD
A1245	A1385	A1065	A1225	A1255	A1265	A1005	A1155	A1175	A1500	
9	10	11	12	13	14	15	16	17	18	
96 x 48	96 x 48	96 x 48	96 x 48	96 x 48	96 x 48	144 x 72	62 x 38	62 x 38	72 x 72	
92 x 45,5	92 x 45	92 x 45	92 x 45	92 x 22,2	92 x 45	138 x 68	60 x 36	60 x 36	68x68	
143	126	130	130	143	130	145	26,5	33	70	
rot	rot	rot / grün	rot / grün	rot / grün	rot / grün	rot / grün	rot / grün / LCD	rot / LCD		
14	14	14	14	14 / 20	14	20	14 / 12,7	10		
		•	•	•			•			
	•									
						•		•		
•						•				
•	•					•				
•	•					•				•
	•					•				
36	1	1	max. 4	9	1 oder 2	1	1	1	2	
Tasten, SW			DIP / ME	Jumper	Tasten					
•										
•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
•/•	•/•	•/•		•/•	•/•	•/•	•/•	•/•	•/•	•/•
•/•	•/•	•/•	•/•		•/•	•/•				
•/-	•/-	•/•			•/-	•/-				
•/-	•/-	•/•			•/-	•/-				
		•/-			•/•	•/•				
•/•	-/•	•/•			•/•	-/•				
					•					
					•					
					•					
•					•					
2										
opt. max. 4	2				max. 4	4				
						•/•				
•/•					•/•	•/•				
	•	•			•					
•/•	-/•	•/-	•/-		-/•	-/•	-/• (opt.)	-/•	-/•	-/•
					-/•					
•/•	•/•	•/•	•/•	•/•	•/•	•/•				
	•/-	•/-	•/-	•/-	•/•	•/-				
•				•						
•		•					•	• (LED)		
•	•	•	opt.		•	•	•	•		
•										

Änderungen vorbehalten.